

Polycom XML Tracer

User's Guide

Version 1.52

October 2007

EDOC2073C Rev_B

Copyright © 2007 Polycom, Inc.
All Rights Reserved

All text and figures included in this publication are the exclusive property of Polycom, Inc. and may not be copied, reproduced or used in any way without the express written permission of Polycom, Inc. Information in this document is subject to change without notice. This document also contains registered trademarks and service marks that are owned by their respective companies or organizations.

If you have any comments or suggestions regarding this document, please send them via e-mail to info@polycom.com.

Catalog No. EDOC2073C Rev_B
Version 1.52

Notice

While reasonable effort was made to ensure that the information in this document was complete and accurate at the time of printing, Polycom, Inc., cannot assume responsibility for any errors. Changes and/or corrections to the information contained in this document may be incorporated into future issues.

Portions, aspects and/or features of this product are protected under United States Patent Law in accordance with the claims of United States Patent No: US 6,300,973; US 6,496,216; US 6,757,005; US 6,760,750; and US7,054,820.

PATENT PENDING

Table of Contents

| | |
|--|-----------|
| Overview | 1 |
| Tracing Methods | 2 |
| Setting up Communication Between the Tracer and the MCU | 3 |
| Configuring the Tracer | 3 |
| Configuring the MGC Manager to Work with the Tracer in Proxy Mode | 4 |
| The Tracer Window | 6 |
| The Tracer Toolbar | 9 |
| The Options Dialog Box | 10 |
| Setting up and Initializing a Schemas Directory | 12 |
| Working with the Tracer Application | 14 |
| Starting and Stopping Tracing | 14 |
| Displaying the Request and Response XML for a Transaction | 15 |
| Displaying and Hiding Element Properties | 16 |
| Searching for Text | 17 |
| Copying Element Names, Paths or Values, or the Complete XML Request or Response to the Clipboard | 18 |
| Displaying Element Values in Hexadecimal Format | 18 |
| Viewing the Schemas on which a Transaction is Based | 19 |
| Saving and Retrieving the Contents of the Transaction History Pane | 19 |
| Clearing the Contents of the Transaction History Pane | 22 |
| Tracing All XML Streams Without Analyzing Requests and Responses | 23 |
| Sending an XML Command to an MCU | 24 |
| Viewing Transaction Statistics | 25 |
| Viewing the Tracer Log | 25 |
| Filtering Messages | 26 |

Overview

The Polycom XML Tracer application enables programmers and testers to view the XML communication between a client application and an MCU. The Tracer lists XML transactions as they occur, and enables you to display the contents of the XML request and corresponding response. Multiple MCUs can be traced simultaneously, each in its own window. The Tracer can be used with MCUs of both the MGC and RMX families.

The Tracer provides a multitude of useful features, such as enabling you to save the contents of the Tracer window to a file for future use, to search for a specified string, and to copy element names, paths, and values to the Clipboard.

The Tracer has a filtering mechanism which enables you to specify which schemas and which actions you want to trace.

The Tracer application (**XmlTracer.exe**) is placed in the MGC Manager root directory, as part of the MGC Manager installation, and is also supplied in the RMX API kit.


Note Before running the Tracer for the first time, you must run the **WinPcap_3_0_nogui.exe** application, which is supplied in the MGC Manager root directory and in the RMX API kit.

Tracing Methods

The Polycom XML Tracer can operate in two modes: Sniffer mode and Proxy mode. The two modes present identical user interfaces and can be used simultaneously. The usual operating mode is Sniffer mode. However, for MGC applications, if the client and server applications are running on the same machine, such as when using the MGC simulator, Proxy mode must be used.

Sniffer Mode


The Tracer has a sniffing module that sniffs the network package which is transported through the network card.



Proxy Mode

Note Proxy mode is only applicable when using the MGC simulator.

The client application uses the Tracer as a proxy. The XML request flows through the Tracer to the MCU, and the response flows through the Tracer to the client application.



Setting up Communication Between the Tracer and the MCU

Configuring the Tracer

To configure the Tracer:

1. On the *Tools* menu, click **Communication**.

The *Communication* dialog box opens.

2. To configure the Tracer to work in Proxy mode, fill in the following parameters:

Note Proxy mode is only applicable when using the MGC simulator.

| Option | Description |
|----------------------|--|
| <i>Listen Port</i> | The listen port number, that is, the MCU proxy port. |
| <i>Transmit Port</i> | The port the MCU is listening to. |
| <i>Transmit IP</i> | The IP of the MCU. |

- To configure the Tracer to work in Sniffer mode, select the **Sniffer** check box and then fill in the following parameters:

Note Proxy mode is always used when working with MCUs of the RMX family. Proxy mode is also used when working with MCUs of the MGC family, with the exception of the MGC Simulator.

| Option | Description |
|--------------------|---|
| <i>Port</i> | The port number. |
| <i>IP Address</i> | The IP address to be sniffed. |
| <i>Net Adapter</i> | The network adapter. |
| <i>Sniff Mode</i> | Select one of the following values to indicate whether one or multiple IP addresses are to be sniffed and traced: <ul style="list-style-type: none"> All the IP from the type X.X.*.* – to sniff all IP addresses with the same two initial components as the IP address specified in the <i>IP Address</i> field Sniff a specific IP address – to sniff only the IP address specified in the <i>IP Address</i> field |

Configuring the MGC Manager to Work with the Tracer in Proxy Mode


If you want to trace the MGC Manager in Proxy mode, you must configure the MGC Manager as described in this section. If you want to trace in Sniffer mode, no configuration of the MGC Manager is necessary.

Note You can only trace the MGC Manager in Proxy mode when the MGC Manager is running in simulation mode. To run the MGC Manager in simulation mode, add "-s" to the target field in the MGC Manager application shortcut.
 (e.g. "C:\Program Files\MGC Manager Ver 8.0\OperWS.exe" -s)

To configure the MGC Manager to work with the Tracer in Proxy mode:

- In the main MGC Manager window, select the **Configure Proxy Settings** option from the *Options* menu.

The *Configure Proxy* dialog box opens.




- Fill in the following parameters:

| Option | Description |
|-------------------|-----------------|
| <i>Proxy IP</i> | The Proxy IP. |
| <i>Proxy Port</i> | The Proxy port. |

- Click **OK**.

4. Right-click on the MCU to be traced. (If the MCU is currently connected, disconnect before right-clicking.)
5. Click **Properties**.

The *Properties* dialog box opens.




The dialog box titled "Product Management Properties" contains the following fields and buttons:

- Name: Product Management
- IP Address: 172.22.188.40
- Product name: Unknown
- MCU Ver:
- MCMS Ver:
- Buttons: OK, Cancel, Advanced >>

6. Click the **Advanced** button.

Additional fields appear in the *Properties* dialog box.




The dialog box titled "Product Management Properties" now includes additional fields and checkboxes:

- Name: Product Management
- IP Address: 172.22.188.40
- Product name: Unknown
- MCU Ver:
- MCMS Ver:
- Port Number: 80 (dropdown menu) | Http
- Checkboxes: ☒ Automatic discovery, ☐ Secured, ☐ Use Proxy (circled in red)
- Buttons: OK, Cancel

7. Select the **Use Proxy** check box and then click **OK**.

The Tracer Window



The Tracer window is divided into the following panes:

- The *Transaction History* pane
- The *Element Properties* pane (this pane may be hidden depending on the configuration options chosen)
- The *Request* pane
- The *Response* pane

When you start the Tracer application, the *Transaction History* pane lists the transactions that have occurred, and the other panes are empty.

The Transaction History Pane

The records in the *Transaction History* pane are color coded as follows:

| Color | Description |
|-------|---|
| Blue | A request for which the response includes a non-error status. |
| Red | A request for which the response includes an error status. |
| Green | A Get request in which the response includes changed data. |

The following information is displayed in the *Transaction History* pane:

Note The order of the columns can be changed using drag and drop.

| Field | Description |
|----------------------|--|
| <i>Name</i> | The name of the schema to which the transaction belongs. |
| <i>Action</i> | The action that was requested. |
| <i>Message ID</i> | The transaction ID. This value is used to identify the request to which a response belongs. |
| <i>Response Size</i> | The size of the response in bytes. <hr/> Note If the response is transferred in zipped format, then the original size of the response will be displayed in brackets after the zipped size. |
| <i>Status</i> | If the transaction failed, this column contains the error status. If a Get transaction contains changed data, this column contains the OBJECT_ID. |

The Request and Response Panes

When you select a transaction in the *Transaction History* pane, the request XML is displayed in the *Request* pane (the lower left pane) and the response XML is displayed in the *Response* pane (the lower right pane). For recent transactions for which the response has not yet been received, the *Request* pane will be empty.

The *Request* and *Response* panes can display the XML either in tree format or in HTML format, as shown below. The format of the display depends on the setting of the **Use HTML Viewer as XML Viewer** option in the *Options* dialog box. For instructions refer to "Displaying the Request and Response XML for a Transaction" on page 15.

Tree Format

| | Value |
|---------------------|-------|
| TRANS_MCU | |
| TRANS_COMMON_PARAMS | |
| MCU_TOKEN | 1620 |
| MCU_USER_TOKEN | 1620 |
| ASYNC | |
| YOUR_TOKEN1 | 0 |
| YOUR_TOKEN2 | 0 |
| MESSAGE_ID | 1211 |
| ACTION | |
| GET_STATE | |

HTML Format

```

- <TRANS_MCU>
- <TRANS_COMMON_PARAMS>
  <MCU_TOKEN>1616</MCU_TOKEN>
  <MCU_USER_TOKEN>1616</MCU_USER_TOKEN>
- <ASYNC>
  <YOUR_TOKEN1>0</YOUR_TOKEN1>
  <YOUR_TOKEN2>0</YOUR_TOKEN2>
</ASYNC>
<MESSAGE_ID>419</MESSAGE_ID>
</TRANS_COMMON_PARAMS>
- <ACTION>
  <GET_STATE />
</ACTION>
</TRANS_MCU>
  
```


The Element Properties Pane

The *Element Properties* pane is only displayed if the **View Schemas Description** option in the *Options* dialog box is selected. For instructions refer to "Displaying and Hiding Element Properties" on page 16.

The *Element Properties* pane displays the properties of the element selected in the *Request* or *Response* pane, for example, the element type and the minimum and maximum occurrences of the element.















Tracing Multiple API Sessions Simultaneously

You can trace multiple API sessions at the same time. Each session is traced in a separate window, as shown below. When the Tracer is running it automatically opens a window whenever you connect to an MCU that it is configured to trace. The title bar of each window contains the IP address of the MCU which is being traced in the window. Most operations that you can perform are applied to the connection whose window is selected at the time.



The Tracer Toolbar

The toolbar provides quick access to the following operations:

| Button | Description |
|---|---|
|  | Opens a saved Transaction History file. |
|  | Saves the contents of the selected <i>Transaction History</i> pane in a file. |
|  | Clears the <i>Transaction History</i> pane for the selected connection. |
|  | Stops tracing all connections. |
|  | Starts tracing all connections. |
|  | Stops tracing the selected connection. |
|  | Starts tracing the selected connection. |
|  | Configures the filter. |
|  | Applies or removes the filter. |
|  | Finds specified text. |
|  | Opens the <i>Options</i> dialog box. |
|  | Opens the <i>Statistics</i> dialog box. |
|  | Allows you to enter an XML command and send it to an MCU. |
|  | For internal use only. |


The Options Dialog Box

The *Options* dialog box enables you to configure the Tracer, as well as to retrieve schema copies from MCUs of the MGC family, in order to initialize the filter.

To open the Options dialog box:

- Click the **Options**  button..

The *Options* dialog box opens.



The *Options* dialog box contains the following options and functions:

| Option | Description |
|---------------------------------|--|
| <i>Maximum Lines of History</i> | The maximum number of lines that can be displayed in the <i>Transaction History</i> pane before it starts to overwrite entries. |
| <i>Clear All</i> | Clears the contents of the <i>Transaction History</i> pane in all open Tracer windows. |
| <i>Auto Save</i> | Saves the contents of the <i>Transaction History</i> pane to a file before entries are overwritten. The files will be created in the history sub-directory of the Tracer home directory. |
| <i>Schemas Directory</i> | The schemas directory to be used for tracer operations such as initializing the filter and viewing the schema to which a transaction belongs. To change the directory, either enter the full path to the directory, or use the Browse button to locate the required directory. |

| Option | Description |
|--------------------------------------|---|
| <i>Get Schemas</i> | <p>Copies the schemas from the MCU you specify to the schemas directory.</p> <hr/> <p>Note This function can only be used with MCUs of the MGC family. When working with MCUs of the RMX family, you must copy the schemas manually from the RMX API kit to the schemas directory.</p> <hr/> |
| <i>Synchronize Schemas</i> | Initializes the filter based on the contents of the schemas in the schemas directory. |
| <i>Schemas Viewer</i> | <p>The application to be used to view the schemas on which a transaction is based. The default is notepad.</p> <p>To specify a different application either select the Notepad, Internet Explorer, or Microsoft Visual Studio buttons, or use the Browse button to locate the required application.</p> |
| <i>Minimize Tracer on startup</i> | Select this check box to minimize the Tracer window at startup. |
| <i>Use HTML Viewer as XML Viewer</i> | <p>Select this check box to display XML requests and responses in HTML format.</p> <p>Clear this checkbox to display XML requests and responses in tree format.</p> |
| <i>View Schemas Description</i> | Select this check box to display a fourth pane in the Tracer window, containing the properties of the element selected in the <i>Request</i> or <i>Response</i> panes. |

Setting up and Initializing a Schemas Directory


Various tracer operations require the use of a schemas directory.

The Tracer provides a function to copy the schemas from an MCU of the MGC family to the schemas directory. When working with MCUs of the RMX family, you must copy the schemas manually from the RMX API kit to the schemas directory.

To assign a schemas directory and optionally copy the schemas from an MCU to the schemas directory:

1. Click the **Options**  button..

The *Options* dialog box opens.




2. In the *Schemas Directory* field, enter the path to the directory to be used as the schemas directory.

3. To copy the schemas from an MCU to the schemas directory:

Note This step is only applicable to MCUs of the MGC family.

- Click **Get Schemas from MCU**.
- The *Get Schemas from MCU* dialog box opens.



- Specify the MCU IP and port, and then click **Start**.
 - The schemas are copied from the MCU to the schemas directory you specified.
4. Click **OK** to exit from the *Options* dialog box.

Working with the Tracer Application



You can perform the following operations when working with the Tracer:

- Start, stop, or resume tracing a specific connection, or all connections.
- Display the request and response XML of a transaction.
- Display or hide element properties.
- Search for text in a selected pane.
- Copy element names, paths, or values to the Clipboard.
- Copy the complete XML request or response to the Clipboard.
- Display element values in hexadecimal format.
- View the schemas that a transaction is based on.
- Save the contents of the *Transaction History* pane in a file.
- View the contents of a saved Transaction History file, including the request and response XML.
- Clear the contents of the *Transaction History* pane.
- Trace all XML streams without analyzing requests and responses.
- Send an XML command to an MCU.
- View statistics about transactions.
- View the Tracer log.

Note You can set up a filter to specify the transactions you want to trace. For instructions see "Filtering Messages" on page 26.

Starting and Stopping Tracing

To start or stop tracing a specific connection:

1. Select the window displaying the required connection.
2. Click the **Start Tracing**  or **Stop Tracing**  button.

To start or stop tracing all connections:

- Click the **Start All Tracing**  or **Stop All Tracing**  button.

Displaying the Request and Response XML for a Transaction

The *Request* and *Response* panes can display the XML in one of two ways; in tree format or in HTML format, as shown below.

Tree Format

| | Value |
|---------------------|-------|
| TRANS_MCU | |
| TRANS_COMMON_PARAMS | |
| MCU_TOKEN | 1620 |
| MCU_USER_TOKEN | 1620 |
| ASYNC | |
| YOUR_TOKEN1 | 0 |
| YOUR_TOKEN2 | 0 |
| MESSAGE_ID | 1211 |
| ACTION | |
| GET_STATE | |

HTML Format

```
- <TRANS_MCU>
- <TRANS_COMMON_PARAMS>
  <MCU_TOKEN>1616</MCU_TOKEN>
  <MCU_USER_TOKEN>1616</MCU_USER_TOKEN>
- <ASYNC>
  <YOUR_TOKEN1>0</YOUR_TOKEN1>
  <YOUR_TOKEN2>0</YOUR_TOKEN2>
</ASYNC>
<MESSAGE_ID>419</MESSAGE_ID>
</TRANS_COMMON_PARAMS>
- <ACTION>
  <GET_STATE />
</ACTION>
</TRANS_MCU>
```

To display the request and response XML for a transaction:


- Select the transaction in the *Transaction History* pane.

The request XML will be displayed in the *Request* pane, and the response XML (if it has arrived) will be displayed in the *Response* pane.

To change the format in which the request and response XML is displayed:

- Click the **Options**  button..

The *Options* dialog box opens.



- Specify the required format as follows:

| To ... | Action |
|-----------------------------|--|
| View the XML in HTML format | Select the Use HTML Viewer as XML Viewer check box. |
| View the XML in tree format | Clear the Use HTML Viewer as XML Viewer check box. |

- Click **OK**

The request and response XML will be displayed in the requested format in all new Tracer windows that are opened.

Note The format of the request and response XML will not be changed in windows that are already open. To change the format for an open window, you must close the window and it will re-open with the requested format.


Displaying and Hiding Element Properties

The Tracer can optionally display the properties of an element selected in the *Request* or *Response* panes. The element properties, such as the element type and the minimum and maximum occurrences of the element, will be displayed in the *Element Properties* pane (the top right pane).

To display or hide the Element Properties pane:

- Click the **Options**  button..

The *Options* dialog box opens.



- Specify whether to display or hide the *Element Properties* pane as follows:

| To ... | Action |
|--|--|
| Display the <i>Element Properties</i> pane | Select the View Schema Description check box. |
| Hide the <i>Element Properties</i> pane | Clear the View Schema Description check box. |

- Click **OK**


The *Element Properties* pane will be shown or hidden, as specified, in all new Tracer windows that are opened.

Note The change will not be applied to windows that are already open. To apply the change to an open window, you must close the window and it will re-open with the change applied.

Searching for Text

The Tracer enables you to search for a message ID in the *Transaction History* pane, and to search for any string in the *Request* and *Response* panes.


To Locate the Transaction with a specified Message ID:

- Click anywhere in the *Transaction History* pane, and then press <Ctrl> + <F> or click . The *Find* dialog box opens.



- Enter the Message ID to be located and then click **OK**.
The *Transaction History* pane scrolls to display the transaction with the specified Message ID.

To Locate text in the Request or Response panes:

- Click anywhere in the *Request* or *Response* pane, and then press <Ctrl> + <F> or click . The *Find* dialog box opens.



- Enter the string to be located and then click **OK**.
The *Request* or *Response* pane scrolls to display the specified string.

Copying Element Names, Paths or Values, or the Complete XML Request or Response to the Clipboard

When viewing XML requests and responses in tree format, you can copy the complete XML request or response, or individual element names, paths, or values to the Clipboard. The following copy options are available from the shortcut menu displayed when you right-click an element in the *Request* or *Response* panes:

| Menu Option | Description |
|----------------------------------|---|
| <i>Copy Element Name</i> | Copies the element name to the Clipboard. |
| <i>Copy Element Value</i> | Copies the element value to the Clipboard. |
| <i>Copy Full Path</i> | Copies the full path of the element to the Clipboard. |
| <i>Copy all XML to Clipboard</i> | Copies the complete request or response XML to the Clipboard. |

Displaying Element Values in Hexadecimal Format

When viewing XML requests and responses in tree format, you can choose to view numeric element values in hexadecimal format. The numeric element values are displayed by default in decimal format.

To display numeric element values in hexadecimal format:

- Right-click in the *Request* or *Response* pane, and then click **Hexadecimal Display**.

The values in the *Request* or *Response* pane will be displayed in hexadecimal format and a check mark is placed next to **Hexadecimal Display** in the right-click menu.

Note If you close the window, then when the window re-opens, the display of numeric element values will revert to decimal format.

To display numeric element values in decimal format:

- Right-click in the *Request* or *Response* pane, and then click **Hexadecimal Display**.

The values in the *Request* or *Response* pane will be displayed in decimal format and the check mark next to **Hexadecimal Display** in the right-click menu is removed.

Viewing the Schemas on which a Transaction is Based


Note Before you can view the schemas, you must set up and initialize a schemas directory. For instructions see "Setting up and Initializing a Schemas Directory" on page 12.

The Tracer enables you to view a list of the schemas on which a transaction is based, (the schema the transaction belongs to, and all schemas included in this schema) and to view the contents of these schemas. By default, schemas are displayed using Notepad. You can use a different application to view the schemas by changing the value of the **Schemas Viewer** field in the *Options* dialog box. For instructions refer to "The Options Dialog Box" on page 10.

To list the schemas on which a transaction is based, and display the contents of a schema:

1. In the *Transaction History* pane, right-click on the transaction for which you want to view a schema.

A shortcut menu appears listing the schemas on which the transaction is based. The request schemas are listed above the separator, and the response schemas are listed below the separator.



2. Click on the schema you want to view.

The schema will be displayed in Notepad or in whichever application was specified in the **Schemas Viewer** field in the *Options* dialog box.

Saving and Retrieving the Contents of the Transaction History Pane

The number of records that can be contained in the *Transaction History* pane is determined by the value specified for the **Maximum Lines of History** option in the *Options* dialog box. Once this number of lines is reached, records will start to be overwritten.

The contents of the *Transaction History* pane can be saved to a file in one of the following ways:


- At any time request to save the current contents of the *Transaction History* pane in a file.
- Configure the Tracer to write the contents of the *Transaction History* pane to a file automatically before they are overwritten.

If a saved file is opened using the Tracer application it will display all the information in the *Transaction History*, *Request*, and *Response* panes.

To save the current contents of the Transaction History pane:

1. Click the **Save**  button.

The *Save As* dialog box opens.




2. Navigate to the directory in which you want to save the Transaction file and enter a name for the file.
3. Click **Save**.

The contents of the *Transaction History* pane will be saved in the specified file.

To automatically save the contents of the Transaction History pane before they are overwritten:

1. Click the **Options**  button..

The *Options* dialog box opens.




2. Select the **Auto Save** check box.

The contents of the *Transaction History* pane will be automatically saved to files before any overwriting occurs. The file names will be generated by the system, for example **historyFile12**. The files will be saved in the **history** sub-directory of the Tracer home directory.

To display the contents of a saved Transaction History file:

1. Click the **Open**  button.

The *Open* dialog box opens.



2. Navigate to the directory containing the file you want to open.
3. Select the file and then click **Open**.


A new window will open in the Tracer containing the contents of the Transaction History file.


Clearing the Contents of the Transaction History Pane

To clear the contents of the currently selected Transaction History pane:

- Click the **Clear History**  button.

To clear the contents of the Transaction History pane in all open tracer windows:

1. Click the **Options**  button..
The *Options* dialog box opens.



2. Click the **Clear All** button.
3. Click **OK** to exit from the *Options* dialog box.

Tracing All XML Streams Without Analyzing Requests and Responses


You can request that the Tracer trace all XML streams without the Tracer analyzing the transactions to identify requests and responses. By default the Tracer analyzes the transactions to identify requests and responses.

To trace all XML streams:

- On the *Tools* menu, click **Trace All XMLs**.

The *Transaction History* pane will display a list of transactions without details such as the Message ID. There will only be one lower pane and this will display the contents of the selected transaction. You can identify the response that belongs to a specific request by searching for the same Message ID.

A check mark is placed next to **Trace All XMLs** in the *Tools* menu.



To revert to displaying XML requests and responses

- On the **Tools** menu, click **Trace All XMLs**.

The *Transaction History* pane will display a list of transactions with details such as the Message ID, and the window will contain *Request* and *Response* panes. The check mark next to **Trace All XMLs** in the *Tools* menu is removed.


Sending an XML Command to an MCU

The Tracer application allows you to enter an XML command and send it to a specified MCU.

To send an XML command to an MCU:

- Click the **Send an XML to server**  button.

The *Send XML to Server* dialog box opens.



2. Fill in the Server Port, the Server ID and the XML command to be sent to the MCU.
3. If you want to log in to the MCU automatically before sending the command, and log out again automatically afterwards, then select the **Send to MGC** check box and specify the User Name and Password to log in with.
4. Click **Send**.


If a tracer window is already open for the connection, the sent transaction will be listed in this window, and the request and response details can be viewed in the lower panes.

If no window is open for the connection, a new tracer window will be opened, and the sent transaction will be listed in this window, together with the login and logout transactions.


Viewing Transaction Statistics

You can display statistics for a connection, such as the number of transactions that have passed since the connection was opened.

To view the statistics for a connection:

- Select the window displaying the required connection, and then click the **Statistics**  button.

The *Statistics* dialog box opens.



The image shows a dialog box titled "Statistics (172.22.188.102)". It contains several fields with the following values:

| Field | Value |
|-------------------------------|------------|
| Time: | 3:31:16 AM |
| Number of transactions: | 50083 |
| Number of unHandled Requests: | 42 |
| Total number of bytes: | 40670212 |
| Bytes per second: | 3208 |
| Average Compression Rate: | 0 |

At the bottom of the dialog box are two buttons: "Reset" and "Close".

Viewing the Tracer Log

The Tracer log file logs errors that occur during the tracing.

To display the Tracer log file:

- On the *Tools* menu, click **Open Log File**.

The Tracer log file is opened using the Notepad application.

Filtering Messages

The Tracer provides a filtering mechanism that enables you to specify which transactions you want to trace. You can specify that all transactions from specific schemas should be traced, or specify the individual actions that should be traced.

Once you have set up the filter, you can specify whether to apply the filter, or to remove it and view all transactions.

When you set up a filter, it is associated with the currently selected window. You can select another window and set up a different filter for it.


When you close the Tracer it will save the filter associated with last window to be closed. When you next run the Tracer it will open with the saved filter.

Before you can configure the filter for the first time, you must set up a schemas directory, and initialize the filter with a list of schemas. For instructions on setting up a schemas directory, see "Setting up and Initializing a Schemas Directory" on page 12.

To initialize the filter:

1. Click the **Options**  button..

The *Options* dialog box opens.




2. Click the **Synchronize Schemas** button.
When the synchronization process is complete, a confirmation message is displayed.
3. Click **OK**.
4. Click **OK** to exit from the *Options* dialog box.


To configure the filter:

1. Click the **Config the Filter**  button.

The *Filter* dialog box opens, displaying a list of schemas.



2. To list the actions in a schema, click the [+] icon next to the schema name. Initially there is a check box next to each schema and each action.




3. Select the check boxes next to the schemas and actions you want to log, and clear the check boxes next to the schemas and actions you want to exclude.

Selecting the check box next to a schema results in all the actions in that schema being selected. Clearing the check box next to a schema results in all the actions in that schema being excluded from the log.

4. To request that all faults should be logged, irrespective of which schema or action they occur in, select the **Show All Faults** check box.
5. To log Get requests only if data has changed since the last Get request, select the **Show Get Request only if Changed** check box.
6. To exclude all Get transactions, click the **Remove Get Transaction** button.
7. Click **OK** to set the filter.

To turn the filter on or off:

- Click the **Apply/Remove the Filter**  button, or on the *Tools* menu, click **Apply Filter** or **Remove Filter** as required.

Proprietary and Confidential

The information contained herein is the sole intellectual property of Polycom, Inc. No distribution, reproduction or unauthorized use of these materials is permitted without the expressed written consent of Polycom, Inc. Information contained herein is subject to change without notice and does not represent commitment of any type on the part of Polycom, Inc. Polycom and Accord are registered trademarks of Polycom, Inc.